

**10998 mounting instructions:**

**Step 1.** Remove the factory stem nut using a 36mm socket and leave the stock washer in place.

**Step 2.** Remove the socket head bolt holding the pivot shaft into the base pivot and slide the shaft out of the pivot to allow access to the flat head bolt used to align the pivot.

**Step 3.** Install the new stem nut onto your stem bolt and torque to OEM specifications (**82 lb/ft**) using the same 36mm socket from step 1. Align the slot in the base pivot to allow front to rear movement of the shaft and tighten the base pivot securely.

**Step 4.** Re-install the shaft and bolt from Step1. Adjust the shaft and top plate to desired angle and tighten the upper and lower pivot bolts. The top plate may be re-positioned by removing the two #6 screws holding it to the top pivot. Once top plate is in the desired position apply the supplied Velcro to the top plate check all

Note: **Check that all fasteners are tight and mount your device. Torque to 82 lb/ft.**

**High Gear Specialties, Inc. 940 W. Oakland Ave. , Suite A10 Oakland, FL 34787**  
**Toll –Free 1 866 341-4192 Fax 1 407 656-3799**

