

## Garmin Quest

The Garmin Quest GPS requires the Garmin motorcycle cradle P/N 010-10610-00 mounting bracket available from your Garmin retailer. To mount onto any TechMount use the 60003 QuickChange Adapter or 60996 Multi-Use Top Plate.



Garmin Quest

Garmin Motorcycle Adapter  
P/N 10-10610-00  
(available from Garmin retailer)



TechMount 60003 Quick Change  
Adapter

The Garmin Quest can be mounted to any TechMount standard top plate using the P/N 60003 Quick Change Adapter by using the Garmin motorcycle adapter P/N 010-10610-00 or equivalent available from your Garmin retailer.

Attach the Garmin bracket to the Quick Change Adapter by aligning the (4) holes in the bracket with the corresponding holes in our adapter using the supplied 7/8" Flat Hd screws with the Nylock nuts. Install the screws thru the Garmin bracket and into our adapter with the nut fitted inside the recessed holes in the underside of our adapter. To mount onto a P/N 60996 Multi-use top plate. Use the same screws and nuts in the same manner as above.

Now mount by sliding the assembly onto any TechMount top plate and align the 1/4" hole in the TechMount plate with the threaded hole in the adapter using the supplied thumbscrew and washers.

