

Motorola v360 Install Help



Motorola v360



Small Cell-phone cradle



P/N 60003 Quick Change Adapter with the P/N 1635 Four Pin Adapter Plate installed.

To mount a Motorola v360 wireless phone
All you need is our small cell-phone cradle with the included P/N 1635 Four Pin Adapter and a P/N 60003 Quick Change Adapter

The first step is to install the P/N 1635 Four Pin Adapter onto the P/N 60003 Quick Change Adapter. Using the (4) 3/8" #6 screws and nuts included with the P/N 60003 kit. (attach the P/N 1635 plate as shown .) Then lock the Small Cell-phone cradle onto the Four Pin Adapter by aligning the pins and firmly sliding together.

The last step is to slide the entire assembly onto any TechMount standard top plate and install the provided thumb screw and lock washer.

