

Stem Mount Installation Instructions:

The Stem Mount is designed to snugly fit into the steering stem hole, in the top triple clamp assembly. If your bike has a rubber plug in this hole, it must be removed.

1. Dampen the rubber o-rings with a small amount of water.
2. Grab the Stem Mount shaft and firmly press and rotate the mount into the top of your steering stem hole until the base of the Stem Mount touches the stem nut. **(Note: Do not push down on the top plate to install, this can cause the mount to fold and cause damage to your tank!)**
3. Adjust the angle of the top plate and shaft to the desired level and tighten with the supplied hex key.
4. Attach the supplied Velcro to the device and to the top plate.

The Stem Mount is removed by pulling upward firmly while rotating slowly.

This mount system is designed to hold small devices such as pagers, cell phones, garage door openers, radar detectors and other devices of similar weight and size. Please ride responsibly!

