



Step 1. Remove the chrome stem nut from your steering stem bolt and leave stock washer in place.

Step 2. Remove this socket head bolt and slide shaft out of the base pivot to allow access to the flat head bolt used to align the mount.

Step 3. Install the new stem nut onto your stem bolt and torque to OEM spec. for the original stem nut. Align the slot in the base pivot to allow front to rear movement of the shaft and tighten.

Step 4. Re-install the shaft and bolt from Step 1.

Check that all fasteners are tight and install the supplied Velcro onto your device. That's it!

New Stem Nut  
Replaces original stem nut.

