

Motorola v360 Install Help



Motorola v360

To mount a Motorola v360 wireless phone
All you need is our small cell-phone cradle with the
included P/N 1635 Four Pin Adapter and a P/N 60003
Quick Change Adapter

The first step is to install the P/N 1635 Four Pin
Adapter onto the P/N 60003 Quick Change Adapter.
Using the (4) 3/8" #6 screws and nuts included with the
P/N 60003 kit. (attach the P/N 1635 plate as shown .)
Then lock the Small Cell-phone cradle onto the
Four Pin Adapter by aligning the pins and firmly
sliding together.



Small Cell-phone cradle

The last step is to slide the entire assembly onto any
TechMount standard top plate and install the provided
thumb screw and lock washer.



**P/N 60003 Quick Change Adapter with the
P/N 1635 Four Pin Adapter Plate installed.**

