

TechMount



Dynojet LCD Mount Instructions:

Step 1. Attach the LCD unit to the Dynojet Top Pin with the supplied LCD mounting screws (Qty. 3)

Step 2. With the LCD secure, now install the Base Extension onto the Display Board using the Base Extension Screw and locknut. Tighten Base Extension firmly so that it will not rotate and install the Dynojet Top Pin into the Base Extension and secure with the Top Pin Screw.

Step 3. To rotate the **LCD unit** angle, loosen the **Top Pin Screw** , adjust and re-tighten.

Step 4.. To remove the LCD unit, remove the **Top Pin Screw** completely and lift the **Top Pin** straight out. This allows the entire unit to be removed safely and quickly.