

Delphi XM MyFi Radio Install Help



XM MyFi cradle included w/ radio



Single Pin Adapter Plate P/N 1637



P/N 60003 Quick Change Adapter with the P/N 1635 Four Pin Adapter Plate installed.

The Delphi MX MyFi radio comes with the power cradle (pictured left). This cradle has a single pin hole in the back of the cradle. In order to mount this cradle onto any TechMount system you will need the P/N 1637 Single Pin Adapter along with a P/N 1635 Four Pin Adapter.

The first step is to install the P/N 1635 Four Pin Adapter onto the P/N 60003 Quick Change Adapter. Using the (4) 3/8" #6 screws and nuts included with the P/N 60003 kit attach the P/N 1635 plate as shown . Then lock the Single Pin Adapter P/N 1637 onto the Four Pin Adapter by aligning the pins and firmly sliding together. Now attach the power cradle by aligning the large pin with the corresponding hole.

The last step is to slide the entire assembly onto any TechMount standard top plate and install the provided thumb screw and lock washer.

