


TechMount

Part # 51001 PIAA Light Mounts



Installation Instructions:

This mount system is designed to mount PIAA 1100X lamps onto 1 1/4" O.D. round bar or tubing.

Step 1 is to install the clamps in the desired position. (Either above or below the bar.) Once in position tighten the two halves of the clamps with the supplied 5/32" hex key.

Step 2 Now remove the black cast aluminum base that comes with the PIAA 1100 lamp. (This base will not be used with our system.) Now simply slide the PIAA 1100X lamp over the base pivot and insert the lamp mounting bolts and tighten using the supplied 1/8" hex key.

Step 3 now that the mount is installed snug all the hardware and check for desired light angle. Adjust the lamp angle using the light mounting bolts.

High Gear Specialties, Inc. , 940 W. Oakland Ave. , Suite A10, Oakland, FL 34787
Toll-free 1 866 341-4192 www.techmounts.com , info@techmounts.com